



RUTLAND COUNTY
GARDEN FURNITURE

Hand-Crafted

ASSEMBLY INSTRUCTIONS

LANGHAM BOOT/LOG STORE

Before you commence the assembly process we recommend that you read these instructions thoroughly beforehand to familiarise yourself with the assembly process and to also check that you have the correct components. If for any reason you need assistance, you can find our contact details on the final page of these instructions.

We highly recommend that any assembly is carried out on a flat, level surface if possible and that you use another person to assist you if necessary.

PACKAGE CONTENTS

- 2 x End panels
- 2 x Base support
- 1 x Back panel
- 1 x Roof
- 1 x Lattice
- 1 x Roof support
- 8 x 75mm screws
- 14 x 65mm screws
- 2 x spacer blocks

TOOLS REQUIRED

- Electric screwdriver with No2 Pozidrive bit
- Or No2 Pozidrive Screwdriver



LANGHAM BOOT STORE

LANGHAM BOOT/LOG STORE

Step 1



Stand the left side end panel upright on a flat surface.

Step 2



Place the 2 spacer blocks as shown, so that the back panel can be mated to the end panel at 90°. Please ensure that the slats in the back panel aren't upside down.

Step 3



Secure the back panel to the side panel by using 2 65mm screws.

Step 4



Now repeat the same process for the other end panel.

LANGHAM BOOT/LOG STORE

Step 5



Insert one of the base supports into the gap in the battens at the bottom of the front posts, ensuring that the supporting batten on the base support is in the lowermost position.

Step 6



Now secure both ends of the base support using 2 75mm screws as shown.

Step 7



Now insert the rear base support, again ensuring that the batten running along its length is correctly oriented.

Step 8



Now you can lower the lattice into the base of store in preparation for attaching the roof.

LANGHAM BOOT/LOG STORE

Step 9



Place the roof on the store and adjust its positioning so that the roof battens are flush with the front posts.

Step 10



Secure the roof to the front posts using 2 of the 65mm screws on both sides.

Step 11



Now secure the rear of the roof, this time using a single 65mm screw in each side.

Step 12



Line up the roof support so that is centred across the store and butted up to the underside of the roof. Secure in place with 2 of the remaining 65mm screws in each end.

LANGHAM BOOT/LOG STORE

Step 13



Your Langham boot store is now complete.

WE HOPE THAT YOU FOUND YOUR PRODUCT QUICK AND EASY TO ASSEMBLE BUT IF NOT AND YOU REQUIRE ANY FURTHER ASSISTANCE OR HAVE ANY QUESTIONS YOU CAN CONTACT US BY TELEPHONE ON: **01778 440803**
EMAIL: INFO@RUTLANDCOUNTYGARDENFURNITURE.CO.UK
WWW.RUTLANDCOUNTYGARDENFURNITURE.CO.UK