



RUTLAND COUNTY
GARDEN FURNITURE

Hand-Crafted

ASSEMBLY INSTRUCTIONS

LYDDINGTON PICNIC BENCH

Before you commence the assembly process we recommend that you read these instructions thoroughly beforehand to familiarise yourself with the assembly process and to also check that you have the correct components. If for any reason you need assistance, you can find our contact details on the final page of these instructions.

We highly recommend that any assembly is carried out on a flat, level surface if possible and that you use another person to assist you if necessary.

PACKAGE CONTENTS

- 1 x Table Top
- 2 x Seats
- 2 x Back Rests
- 2 x A-frames
- 2 x Braces
- 4 x L-shaped Back Rest Supports
- 20 x 70mm Coach Screws
- 20 x 60mm Coach Screws
- 64 x Cover Caps

* 7 and 8ft version additionally includes - 2 x seat supports and 4 x braces,
12 x 60mm Coach screws and 12 x cover caps.

TOOLS REQUIRED

- 10mm socket or spanner



LYDDINGTON PICNIC BENCH

LYDDINGTON PICNIC BENCH

Step 1



Ensure that you have all of the correct parts as listed on the front page of these instructions, including any fixings.

Step 2



Lay the table top upside down on a clean, flat surface taking care not to damage it. Now line up one of the table A-frames centrally on the table top as shown in step 3.

Step 3



Place one of the table A-frames centrally against the fixing batten ensuring that the gap at the table edge is the same on both sides.

Step 4



Now, using 2 of the supplied 70mm coach screws and the pre drilled holes, secure the table A-frame to the fixing batten on the table top.

LYDDINGTON PICNIC BENCH

Step 5



Place a cross brace in position as shown, ensuring that it is flush with the underside of the table A-frame and lined up centrally on the table and attach it to the A-frame with a 60mm coach screw.

Step 6



Make sure that the brace is still aligned centrally on the table and affix the other end to the table top with a 60mm coach screw as shown. Repeat steps 3 -6 to finish the table assembly and proceed to step 7.

Step 7



Locate the letter on each of the A-frames where the back rest supports will be located...

Step 8



...and find the corresponding back rest support. There will be an A, B,C and D.

LYDDINGTON PICNIC BENCH

Step 9



Offer up the back rest support to the A-Frame as shown in the image and attach back rest support using 2 x 60mm coach screws, first into the A-frame cross member...

Step 10




...and then 2 more into the A-Frame leg.

Step 11



Repeat steps 7 - 10 until you have attached all of the back rest supports as shown above.

Step 12



For a 7 or 8ft model, follow Steps 12 to 15. Place one of the seat panels upside on a flat surface and place the seat support adjacent to the centre batten...

LYDDINGTON PICNIC BENCH

Step 13



...and aligned centrally on the seat panel before fixing into place with 2 x 60mm coach screws as shown.

Step 14



Now place the brace set support brace as shown so that it is also aligned centrally...

Step 15



...before fixing into place with a 60mm coach screw through the brace into both the seat support and the underside of the seat panel. Add a second brace to the other side of the support in the same way. Repeat steps 12 to 15 for the remaining seat.

Step 16



Place the seat panels on the A-Frames and ensure that the back of the seat panel lines up with the pencil mark on the top of the A-frame cross member.

LYDDINGTON PICNIC BENCH

Step 17



Once lined up correctly, secure the seat in place using 2 x 70mm coach screws.

Step 18



Repeats steps 12 -13 so that both seat panels are fixed in place as shown.

Step 19



Now offer up one the back rest panels and fix into place with 70mm coach screws at both ends of the bench, ensuring that the top of the back rest panel batten is flush with the top of the back rest support as shown in the image. Repeat for the other back panel.

Step 20



Finally, cover any exposed coach screw heads with the cover caps provided. Your Lyddington picnic bench set is now complete.

WE HOPE THAT YOU FOUND YOUR PRODUCT QUICK AND EASY TO ASSEMBLE BUT IF NOT AND YOU REQUIRE ANY FURTHER ASSISTANCE OR HAVE ANY QUESTIONS YOU CAN CONTACT US BY TELEPHONE ON: 01778 440803

EMAIL: INFO@RUTLANDCOUNTYGARDENFURNITURE.CO.UK

WWW.RUTLANDCOUNTYGARDENFURNITURE.CO.UK

Rutland County Garden Furniture Ltd, Ashbourne House, 2 Dovecote Meadows,
Aslackby, Sleaford, Lincs, NG34 0HZ.
Company No: 11025348 VAT No: 282569762