



RUTLAND COUNTY
GARDEN FURNITURE

Hand-Crafted

ASSEMBLY INSTRUCTIONS

THISTLETON GARDEN SEAT

Before you commence the assembly process we recommend that you read these instructions thoroughly beforehand to familiarise yourself with the assembly process and to also check that you have the correct components. If for any reason you need assistance, you can find our contact details on the final page of these instructions.

We highly recommend that any assembly is carried out on a flat, level surface if possible and that you use another person to assist you if necessary.

PACKAGE CONTENTS

- 2 x End frames
- 1 x Seat (5 slats)
- 1 x Back Rest (5 slats)
- 8 x 70mm Coach screws
- 4 x 65mm Screws
- 8 x Cover caps

TOOLS REQUIRED

- 10mm socket or spanner
- Electric screwdriver with No2 Pozidrive bit
- Or No2 Pozidrive Screwdriver



THE THISTLETON GARDEN SEAT

THISTLETON GARDEN SEAT

Step 1



Ensure that you have all of the correct parts as listed on the front page of these instructions, including any fixings.

Step 2



On a flat, level surface, slot the lipped seat panel into one of the end frames as shown above.

Step 3



Now lift up the other side of the seat panel to locate the other end in place. (It is recommended you use an assistant for this step if possible).

Step 4



Align the seat panel flush with the front edge of the end frame as shown and secure in place using 2 of the 65mm screws. Repeat for the other end panel.

THISTLETON GARDEN SEAT

Step 5



Working from underneath the seat panel use 2 x 70mm coach screws to attach the seat panel to the end frame and then repeat for the other end panel.

Step 6



Locate the back rest panel in position with its battens between the end panel uprights and the upper edge of the batten flush with the top of the upright. Secure in place using 2 x 70mm coach screws in each end. (It is recommend you use an assistant for this step if possible).

Step 7



Cover any exposed screws heads with the cover caps provided. Your Thistleton bench is now complete.

WE HOPE THAT YOU FOUND YOUR PRODUCT QUICK AND EASY TO ASSEMBLE BUT IF NOT AND YOU REQUIRE ANY FURTHER ASSISTANCE OR HAVE ANY QUESTIONS YOU CAN CONTACT US BY TELEPHONE ON: **01778 440803**
EMAIL: INFO@RUTLANDCOUNTYGARDENFURNITURE.CO.UK
WWW.RUTLANDCOUNTYGARDENFURNITURE.CO.UK

Rutland County Garden Furniture Ltd, Ashbourne House, 2 Dovecote Meadows,
Aslackby, Sleaford, Lincs, NG34 0HZ.
Company No: 7670072 VAT No: 151744027