



RUTLAND COUNTY
GARDEN FURNITURE

Hand-Crafted

ASSEMBLY INSTRUCTIONS

THE STORYTELLER CHAIR

Before you commence the assembly process we recommend that you read these instructions thoroughly beforehand to familiarise yourself with the assembly process and to also check that you have the correct components. If for any reason you need assistance, you can find our contact details on the final page of these instructions.

We highly recommend that any assembly is carried out on a flat, level surface if possible and that you use another person to assist you if necessary.

PACKAGE CONTENTS

- 1 x Chair back
- 1 x Seat panel
- 1 x Lower frame
- 2 x Arm uprights
- 2 x Arms
- 3 x 60mm, 7 x 70mm & 4 x 120mm M8 Coach screws
- 4 x 75mm screws

TOOLS REQUIRED


- 10mm socket or spanner
- Electric screwdriver with No2 Pozidrive bit
- Or No2 Pozidrive Screwdriver



THE STORYTELLER CHAIR


THE STORYTELLER CHAIR

Step 1



Ensure that you have all of the correct parts as listed on the front page of these instructions, including any fixings.

Step 2



Lay the Chair back on a clean, flat surface taking care not to damage it.

Step 3



Align the Seat panel centrally on the Chair back as shown so that the fixing holes align with those in the Chair back and secure into place with 3 x 70mm coach screws.

Step 4



Now align the Lower frame on the Chair back as shown and after aligning the fixing holes as in Step 3....

THE STORYTELLER CHAIR

Step 5



...fix into place using 3 x 60mm coach screws.

Step 6




Using an assistant, lift the back assembly into a vertical position as shown.

Step 7



Take one of the Arm uprights, align it vertically with the pre-drilled hole in the Seat panel and secure into place with a 120mm coach screw.

Step 8



Now secure the bottom of the Arm upright into the lower frame with another 120mm coach screw.

THE STORYTELLER CHAIR

Step 9



Repeat Steps 7 - 8 for the remaining Arm upright.

Step 10




Take one of the Arms, place it so that the underside is flat on top of the Post and the square end is butted against the Chair back. Now align its outer edge with the edge of the Chair back and the Post.

Step 11



Drive 2 x 75mm screws through the pre-drilled holes in the arms into the top of the Arm upright.

Step 12



Adjust the Arm vertically so that the pre-drilled holes in the Chair back align with those in the Arm ends before securing into place with 2 x 70mm coach screws as shown.

THE STORYTELLER CHAIR

Step 13



Repeat Steps 12 to 14 for the remaining Arm. Your Storyteller chair is now complete.

WE HOPE THAT YOU FOUND YOUR PRODUCT QUICK AND EASY TO ASSEMBLE BUT IF NOT AND YOU REQUIRE ANY FURTHER ASSISTANCE OR HAVE ANY QUESTIONS YOU CAN CONTACT US BY TELEPHONE ON: **01778 440803**

EMAIL: INFO@RUTLANDCOUNTYGARDENFURNITURE.CO.UK

WWW.RUTLANDCOUNTYGARDENFURNITURE.CO.UK

Rutland County Garden Furniture Ltd, Ashbourne House, 2 Dovecote Meadows,
Aslackby, Sleaford, Lincs, NG34 0HZ.
Company No: 7670072 VAT No: 151744027