RUTLAND COUNTY
GARDEN FURNITURE

Hand-Crafted

Assembly Instructions

Empingham 6/4ft log store

Before you commence the assembly process we recommend that you read these instructions thoroughly beforehand to familiarise yourself with the assembly process and to also check that you have the correct components. If for any reason you need assistance, you can find our contact details on the final page of these instructions.

We highly recommend that any assembly is carried out on a flat, level surface if possible and that you use another person to assist you if necessary. **Note:** 38mm black screws are only included with door option.

Package contents

3 x Doors
2 x End panels
3 x Back panels
1 x Base
1 x Lattice
1 x Roof
4 x Centre Posts
4ft x 42, 6ft x 48 Shorter green screws
16 x Longer green screws (For the Base only)
10 x 38mm black screws (For doors only)
2 x Spacer Blocks

Tools required

Electric screwdriver with No2 Pozidrive bit
Or No2 Pozidrive Screwdriver

Empingham Log Store

Empingham 6/4ft log store

Step 1

Stand the left hand end panel (or right hand for the reversed roof version) upright on a flat, level surface.

Step 2

Arrange the 2 spacer blocks on the ground (the orientation is not critical), adjacent to the end panel as shown in the photo above. Now place a back panel on the blocks, at 90° to the end panel, aligning the 2 panels ready for fixing.

Step 3

Using the shorter green screws provided, attach the batten on the back panel to the post of the end panel through the pre-drilled holes, ensuring that the batten remains vertically aligned to the post.

Step 4

Align one of the longer posts (shorter for a reversed roof) with the other end of the back panel.

Empingham 6/4ft log store

Step 5

Attach the panel to the post by screwing through the batten using a short green screw as before.

Step 6

Rearrange the spacer blocks and offer up the next panel, aligning and attaching it as before.

Step 7

Repeat step 6 so that all 3 back panels are now attached.

Step 8

Remove the blocks from beneath the 3rd panel and then slide the base into position as shown.

Empingham 6/4ft log store

Step 9

Attach the base to the end panel front post first, using 2 of the longer green screws.

Step 10

Now attach the base to the end panel rear post using two more longer green screws.

Step 11

Using more of the longer green screws now attach the base to the rear posts as shown.

Step 12

Slide the remaining end panel into place as shown above and attach it to the frame as you did with the first end panel with longer green screws into the front and rear posts. If you are fitting a kindling shelf, omit steps 13 -15 and attach the front posts before fitting the kindling shelf, lattice and then attaching the roof.

Empingham 6/4ft log store

Step 13

Carefully place the roof on top of the end panel posts ensuring that the batten ends sit flush with the posts as shown. Now attach the roof to each end panel post with shorter green screws.

Step 14

Secure the rear of the roof using shorter green screws as shown.

Step 15

Sit the lattice in the store so that it is leaning against the back panel as shown above, so that you have enough clearance to attach the front posts as shown in the next step.

Step 16

Locate the pencil guide marks on the front face of the base. This is where the centre posts will be fitted.

Empingham 6/4ft log store

Step 17

With the centre post lined up with the guide marks on the base, locate the top of the post between the central roof battens, flush with the batten ends, and secure in place with 2 of the shorter green screws.

Step 18

Check the positioning of the post within the guide marks once again before securing the bottom of the centre post with 2 more of the longer green screws. Repeat steps 16 - 18 for the remaining centre post.

Step 19

Your Empingham log store is now complete. If you are fitting doors, please proceed with step 20.

Step 20

Place a spacer block at the front of the log store adjacent to the front end post and rest the hinge side of the appropriate door on the block, aligning it vertically and horizontally for a good fit. Now use four of the supplied black hinge screws to affix the hinge to the post.

Empingham 6/4ft log store

Step 21

Align the top hinge in place, ensuring that the gap between the door and post is consistent at top and bottom.

Step 22

Secure the top hinge in place using more of the black hinge screws. Repeat steps 20 - 22 for any further doors as required.

We hope that you found your product quick and easy to assemble but if not and you require any further assistance or have any questions you can contact us by telephone on: **01778 440803**
Email: info@rutlandcountygardenfurniture.co.uk
www.rutlandcountygardenfurniture.co.uk