



RUTLAND COUNTY
GARDEN FURNITURE

Hand-Crafted

ASSEMBLY INSTRUCTIONS

RUTLAND BOX PERGOLA

Before you commence the assembly process we recommend that you read these instructions thoroughly beforehand to familiarise yourself with the assembly process and to also check that you have the correct components. If for any reason you need assistance, you can find our contact details on the final page of these instructions.

We highly recommend that any assembly is carried out on an open flat, level surface if possible with sufficient space. You will also require the assistance of 2 adults to complete assembly safely.

Please note: For a free-standing pergola you can remove up to 600mm from the bottom of each post prior to commencing construction

PACKAGE CONTENTS

- 4 x Posts
- 2 x Runners
- 2 x Edge rafters
- 4 x Rafters
- 4 x Short corner braces
- 4 x Long corner braces
- 8 x M8 120mm Coach screws
- 16 x M8 100mm Coach screws
- 12 x 70mm woodscrews
- 8 x 60mm woodscrews

TOOLS REQUIRED


- 10mm socket drive or spanner
- No2 Posidriv screwdriver
- Platform or Step ladder



THE RUTLAND BOX PERGOLA


RUTLAND BOX PERGOLA

Step 1




Check that you have the correct components as shown in the package contents, including any fixings.

Step 2



Lay one of the runners down (part with timber batten attached) with the batten uppermost. Position one of the posts as shown, so that it is butted against the batten and the top face of the post is flush with the top edge of the runner. Now fix the post in place using 2 of the 100mm coach screws and repeat for remaining posts and runner.

Step 3



Lay the two complete frame assemblies opposite each other, batten side uppermost, as shown and space the bottom of the opposing posts apart by a distance corresponding to the size of pergola you are constructing. e.g. 2.4 metres for a 2.4 metre pergola.

Step 4



Using as many assistants as necessary, lift the end assemblies from the runner side, up into the vertical position.

RUTLAND BOX PERGOLA

Step 5



Using a platform or step ladder (and an assistant if necessary) lift one of the plain Edge rafters into position so that both ends are butted up to the inner edge of the rafter and flush with its top and bottom edges as shown...

Step 6



...before using 2 x 100mm coach screws to fix it to the post.

Step 7



Now repeat this process for the other end assembly, adjusting its position as necessary...

Step 8



...before adding the second Edge rafter in the same fashion.

RUTLAND BOX PERGOLA

Step 9



Add the corner braces as shown i.e. one long, one short; fixed in place with 2 x 70mm woodscrews for the short brace and a single 70mm plus 2 x 60mm screws into the rafter for the longer brace.

Step 10



Working from within the structure you have assembled, locate the markings on the upper edge of the runner batten and lift one of the notched rafters into place so that the rafter sits within the markings at both ends before fixing it into place with a 120mm coach screw in each end.

Step 11



Continue adding the remaining rafters...

Step 12



...until they have all been added.

RUTLAND BOX PERGOLA

Step 13



The Box Pergola construction is now complete. It can remain freestanding or for more security the legs can be sunk into the ground and concreted in place.

Optional Step



Attach the optional Pedestal panels to the bottom of each post as shown. Line up each panel on the post so that it is flush with the bottom face and secure each one into place with 4 x woodscrews.

WE HOPE THAT YOU FOUND YOUR PRODUCT QUICK AND EASY TO ASSEMBLE BUT IF NOT AND YOU REQUIRE ANY FURTHER ASSISTANCE OR HAVE ANY QUESTIONS YOU CAN CONTACT US BY TELEPHONE ON: 01778 440803

EMAIL: INFO@RUTLANDCOUNTYGARDENFURNITURE.CO.UK

WWW.RUTLANDCOUNTYGARDENFURNITURE.CO.UK